HORSE WALKER Upside-Down Horse Walker

COLUMBUS



Horses need exercise!

In the wild horses move between 30 and 50 km on a daily basis while they are grazing. In order to keep your horses health and strong they do need to be able to move around enough. A lack of exercise influences the horses' mental state negatively and often results in problems of their locomotor system. The exercise with a rider is often not enough therefore we need to consider other options in oder to keep our four-legged friends healthy. Our horse walkers do exactly that they keep horses happy by offering exercise which serves the purpose of increasing and maintaining health and strength. The Columbus horse walkers are especially renowend in professional settings for their effective performance, high-qualtiy materials and safety measures. Muscle strength, vitality and stamina are trained with the right intensity.



Double benefits – clever and neat!

Our upside-down horse walker with central round-pen offers you the possibility to make use of the available space perfectly. Futhermore, you are able to train your horses properly even in bad weather conditions.





The upside-down horse walker

A high-quality technical concept which consists of strong support arms and a classic drive unit with a cover. Our horse walker has by default a variety of safety measures as for example the light weight, impactresistant and equine friendly pushers with bars.

-We also offer the fitting track surfaces and round-pen footings-

Columbus Professional Horse Equipment Eigentümer: Andreas Wegmann Lissendorfer Strasse 19 D - 54584 Gönnersdorf

All changes, errors and misprints reserved

Tel: 0049 (0)6597 961092 Fax: 0049 (0)6597 961093 Email: info@columbus-de.com Web: www.columbus-de.com

HORSE WALKER Upside-Down Horse Walker

Product Details Control Panel WBC 2.1 and upside-down horse walker

Standard Control Panel WCB 2.1

Speed

Max. Speed Direction

Time interval programmable


- IP certification Connection voltage Power connection Connection of system Emergency stop Control panel Dimensions Mounting brackets Optional
- Standard walk-trot control
- Electronik break system
- Safety Slip System
- Silent during operation
- Power consumption 0,6 kW/h
- Industrial drive

adjustable with speedometer (P) adjustable with speedometer (V) 16 km/h automatic left right Setting 1 L P/ R P Setting 2 L P/ R P/ L V/ R V Choice between 5/10/15 min. Setting 1 L P/ R P Setting 2 L P/ R P/ L V/ R V IP 65 230 Volt 50 Hz 1,5 m cable and plug pin plug IP65 connection yellow/red switch material impact-resistant polyester 25x30x17cm inclusive on/of switch for low current system



COLUMBUS

Columbus Professional Horse Equipment Eigentümer: Andreas Wegmann Lissendorfer Strasse 19 D - 54584 Gönnersdorf



- Low maintenance ^
- Equipped with strong support bearing
- All steel parts are galvanized according to German standards
- CE- certified
- Roof constructions are calculated concidering snow load



Tel: 0049 (0)6597 961092 Fax: 0049 (0)6597 961093 Email: info@columbus-de.com Web: www.columbus-de.com

All changes, errors and misprints reserved